

Informationen zur Gebrauchsanleitung

Lesen Sie vor dem ersten Gebrauch des Produktes diese Gebrauchsanleitung sorgfältig durch und bewahren Sie diese für spätere Fragen und weitere Nutzer auf. Sie ist ein Bestandteil des Produktes. Hersteller und Importeur übernehmen keine Haftung, wenn die Angaben in dieser Gebrauchsanleitung nicht beachtet werden. Sollten Sie Fragen zum Produkt sowie zu Ersatz- / Zubehörteilen haben, wenden Sie sich an den Kundenservice über unsere Website: www.ds-group.de/kundenservice

BESTIMMUNGSGEMÄßER GEBRAUCH

- Das Produkt ist zum Entfernen von Fusselknoten auf Textilien, wie z. B. Kleidungsstücken, Sofas und Kissenbezügen bestimmt.
- Nur für den privaten Gebrauch, nicht für eine gewerbliche Nutzung bestimmt.
- Das Produkt nur wie in der Gebrauchsanleitung beschrieben nutzen. Jede weitere Verwendung gilt als bestimmungswidrig.
- Von der Gewährleistung ausgeschlossen sind alle Mängel, die durch unsachgemäße Behandlung, Beschädigung oder Reparaturversuche entstehen. Dies gilt auch für den normalen Verschleiß.

SYMBOLE



Gefahrenzeichen: Dieses Symbol zeigt mögliche Gefahren an. Die dazugehörigen Sicherheitshinweise aufmerksam lesen und befolgen.



Ergänzende Informationen



Gebrauchsanleitung vor Benutzung lesen!



Gleichstrom



SICHERHEITSHINWEISE

- Das Produkt und das Verpackungsmaterial von Kindern und Tieren fernhalten. Es besteht Verletzungs- und Erstickungsgefahr!
- Dieses Produkt kann von **Kindern** ab 8 Jahren sowie von Personen mit reduzierten physischen, sensorischen oder mentalen Fähigkeiten oder Mangel

an Erfahrung und/oder Wissen benutzt werden, wenn sie beaufsichtigt oder bezüglich des sicheren Gebrauchs des Produktes unterwiesen wurden und die daraus resultierenden Gefahren verstanden haben.

- Das Produkt ist **kein** Spielzeug. Kinder dürfen **nicht** mit dem Produkt spielen. Kinder und Tiere nicht mit dem Produkt unbeaufsichtigt lassen!
- Reinigung und **Benutzer-Wartung** dürfen **nicht** durch **Kinder** durchgeführt werden, es sei denn, sie sind älter als 8 Jahre und werden beaufsichtigt.
- Die Klingen sind scharf! Alle Köperteile vom Klingeneinsatz fernhalten. Nicht auf der Haut anwenden! Den Klingeneinsatz nicht auseinandernehmen! Es besteht Schnittgefahr!
- Batterien können bei Verschlucken lebensgefährlich sein. Batterien und Produkt für Kinder und Tiere unerreichbar aufbewahren. Wurde eine Batterie verschluckt, muss sofort medizinische Hilfe in Anspruch genommen werden. Es besteht Verätzungsgefahr durch Batteriesäure!
- Sollte eine Batterie auslaufen, Körperkontakt mit der Batteriesäure vermeiden. Gegebenenfalls Schutzhandschuhe tragen. Bei Kontakt mit Batteriesäure die betroffenen Stellen sofort mit reichlich klarem Wasser spülen und umgehend medizinische Hilfe in Anspruch nehmen. Es besteht Verätzungsgefahr durch Batteriesäure!
- Das Produkt vor jeder Inbetriebnahme auf Beschädigungen überprüfen. Das Produkt nicht verwenden, wenn es sichtbare Schäden aufweist.
- Das Produkt nicht ohne Lochaufsatz und Fusselbehälter benutzen.
- Niemals versuchen, das Produkt selbst zu reparieren oder auseinanderzunehmen. Bei Fehlfunktionen oder Schadensfällen den Kundenservice kontaktieren.
- Nur den im Kapitel „Technischen Daten“ angegebenen Batterietyp verwenden.
- Beim Einsetzen der Batterien (Batteriefach auf der Oberseite des Produktes) immer auf die korrekte Polarität achten.
- Immer alle Batterien ersetzen. Keine verschiedenen Batterietypen, -marken oder Batterien mit unterschiedlicher Kapazität benutzen.
- Batterien aus dem Produkt herausnehmen, wenn diese verbraucht sind oder das Produkt länger nicht benutzt wird. So werden Schäden durch Auslaufen vermieden.

- Ausgelaufene Batterien sofort entfernen und die Kontakte im Produkt reinigen.
- Keine schweren Gegenstände auf das Produkt stellen.
- Das Produkt schützen vor: Feuer und anderen Wärmequellen, lang anhaltender, direkter Sonneneinstrahlung, extremen Temperaturen, lang anhaltender Feuchtigkeit, Nässe und Stößen.
- Die Motoreinheit niemals in Wasser oder andere Flüssigkeiten eintauchen! Sicherstellen, dass die Motoreinheit nicht ins Wasser fallen oder nass werden kann. Nicht auf feuchten Textilien benutzen.

LIEFERUMFANG

1 x Fusselrasierer

1 x Fusselbehälter

1 x Abstandshalter

2 x AA-Batterie

1 x Reinigungsbürste

1 x Gebrauchsanleitung

Den Lieferumfang auf Transportschäden überprüfen. Bei Schäden den Kundenservice kontaktieren. Eventuelle Folien, Aufkleber oder Transportschutz vom Produkt abnehmen. **Niemals das Typenschild und eventuelle Warnhinweise entfernen!**

PRODUKTÜBERSICHT

1 Ein-/Aus-Schalter

2 Batteriefachdeckel

3 Fusselbehälter

4 Reinigungsbürste

5 Abstandshalter

6 Lochaufsatz

7 Klingeneinsatz



BENUTZUNG

1. Je nach Textiloberfläche den Abstandshalter auf den Lochaufsatz stecken bzw. von diesem abnehmen:
 - **Größere** Oberfläche: **mit** Abstandshalter
 - **Feinere** Oberfläche: **ohne** Abstandshalter
2. Einschalten: Den Ein- / Aus-Schalter auf die Position **on** schieben.
3. Das zu bearbeitende Textil auf einen ebenen, festen Untergrund legen und mit kreisenden Bewegungen über die entsprechenden Stellen des Textils fahren.
4. Ausschalten: Den Ein- / Aus-Schalter auf die Position **off** schieben.
5. Das Produkt reinigen.



Bei zu starken Fusseln schaltet sich das Produkt automatisch ab.
In diesem Fall die Batterien herausnehmen und das Produkt reinigen.

REINIGUNG UND AUFBEWAHRUNG

- Vor der Reinigung die Batterien aus dem Produkt herausnehmen.
- Zum Reinigen keine scharfen oder scheuernden Reinigungsmittel oder Reinigungspads verwenden. Diese können die Oberflächen beschädigen.
- Den Fusselbehälter aus der Motoreinheit ziehen und ausleeren. Beim Wiedereinsetzen darauf achten, dass er einrastet.
- Ggf. den Abstandshalter abziehen und den Lochaufsatz abschrauben. Den Klingeneinsatz mit der mitgelieferten Reinigungsbürste reinigen.
- Die Fusselbürste regelmäßig von Fusseln befreien.
- Fusselbehälter, Abstandshalter und Lochaufsatz können mit klarem Wasser abgespült werden, müssen aber vor dem Wiedereinsetzen vollständig trocken sein.
- Die Motoreinheit bei Bedarf mit einem weichen, trockenen Tuch abstauben. Stärkere Verschmutzungen können mit einem leicht feuchten Tuch abgewischt werden.
- Das Produkt an einem trockenen, vor Sonne geschützten sowie für Kinder und Tiere unzugänglichen Ort aufbewahren.

TECHNISCHE DATEN

Artikelnummer:	11096
Modellnummer:	LW-5301
Spannungsversorgung:	3 V \equiv (2 x Typ AA Batterie)
ID Gebrauchsanleitung:	Z 11096 M DS V1.1 0624 as



ENTSORGUNG



Das Verpackungsmaterial umweltgerecht entsorgen und der Wertstoffsammlung zuführen.



Das nebenstehende Symbol (durchgestrichene Mülltonne mit Unterstrich) bedeutet, dass Altgeräte nicht in den Hausmüll, sondern in spezielle Sammel- und Rückgabesysteme gehören.

Besitzer von Altgeräten haben Altbatterien und Altakkumulatoren, die nicht vom Altgerät umschlossen sind und zerstörungsfrei entnommen werden können, aus dem Altgerät zu entnehmen und separat zu entsorgen (siehe auch Abschnitt zur Batterieentsorgung).

Besitzer von Altgeräten aus privaten Haushalten können diese bei den Sammelstellen der öffentlich-rechtlichen Entsorgungsträger oder bei den von Herstellern und Vertriebern im Sinne des ElektroG eingerichteten Rücknahmestellen unentgeltlich abgeben, damit sie einer umweltschonenden Entsorgung sowie einer Wiedergewinnung von wertvollen Rohstoffen zugeführt werden können. Bei einer unsachgemäßen Entsorgung können giftige Inhaltsstoffe in die Umwelt gelangen, die gesundheitsschädigende Wirkungen auf Menschen, Tiere und Pflanzen haben. Rücknahmepflichtig sind auch Geschäfte, die Elektro- und Elektronikgeräte auf dem Markt bereitstellen.



Batterien und Akkus dürfen nicht zusammen mit dem Hausmüll entsorgt werden. Verbraucher sind gesetzlich dazu verpflichtet, Batterien und Akkus einer getrennten Sammlung zuzuführen.

Batterien und Akkus können unentgeltlich bei einer Sammelstelle der Gemeinde/ des Stadtteils oder im Handel abgegeben werden, damit sie einer umweltschonenden Entsorgung sowie einer Wiedergewinnung von wertvollen Rohstoffen zugeführt werden können. Bei einer unsachgemäßen Entsorgung können giftige Inhaltsstoffe in die Umwelt gelangen, die gesundheitsschädigende Wirkungen auf Menschen, Tiere und Pflanzen haben.

Batterien und Akkus nur in entlademem Zustand abgeben. Wenn möglich wiederaufladbare Batterien anstelle von Einwegbatterien verwenden.

Bei lithiumhaltigen Batterien und Akkus vor der Entsorgung die Pole abkleben, um einen Kurzschluss zu vermeiden. Ein Kurzschluss kann zu einem Brand oder einer Explosion führen.

Die Abfallvermeidung leistet einen noch wertvolleren Beitrag zum Umweltschutz. Sofern möglich, ist daher neben einer weiteren eigenen Nutzung oder Reparatur auch die Abgabe an Zweitnutzer eine ökologisch wertvolle Alternative zur Entsorgung.

DS Produkte GmbH

Stormarnring 14, 22145 Stapelfeld, Deutschland

KUNDENSERVICE

Am Heisterbusch 1, 19258 Gallin, Deutschland

kundenservice@dspro.de

☎ +49 38851 314650*

* Anruf in das deutsche Festnetz zum Tarif Ihres Anbieters.

Information About the Operating Instructions

Before using the product for the first time, please read through these operating instructions carefully and keep them for future reference and other users. They form an integral part of the product. The manufacturer and importer do not accept any liability if the information in these operating instructions is not complied with.

If you have any questions about the product and about spare parts /accessories, contact the customer service department via our website:

www.ds-group.de/kundenservice

INTENDED USE

- The product is intended to be used to remove lint nodes on textiles such as items of clothing, sofas and cushion covers.
- The product is for personal household use only and is not intended for commercial applications.
- The product should only be used as described in these Operating instructions. Any other use is deemed to be improper.
- Defects arising due to improper handling, damage or attempts at repair are excluded from the warranty. This also applies to normal wear and tear.

SYMBOLS



Danger symbols: This symbol indicates possible dangers. Read through the associated safety notices carefully and follow them.



Read the operating instructions before use!



Supplementary information



Direct current



SAFETY NOTES

- Keep the product and the packaging material away from children and animals. There is a danger of injury and suffocation!
- This product may be used by **children** aged 8 and over and by people with reduced physical, sensory or mental abilities or a lack of experience and/or knowledge if they are supervised or have received instruction on how to use the product safely and have understood the dangers resulting from this.
- The product is **not** a toy. Children must **not** play with the product. Do not leave children and animals unsupervised with the product!
- Cleaning and **user maintenance** must not be carried out by **children**, unless they are older than 8 years of age and are supervised.
- The blades are sharp! Keep all body parts away from the blade insert. Do not use on the skin! Do not disassemble the blade insert! There is a danger of cutting.
- Batteries can be deadly if swallowed. Keep batteries and product out of the reach of children and animals. If a battery is swallowed, seek medical assistance immediately. There is a danger of burns from battery Acid!
- If a battery leaks, avoid physical contact with the battery acid. Wear protective gloves if necessary. If you touch battery acid, rinse the affected area with abundant fresh water immediately and contact a doctor as soon as possible. There is a danger of burns from battery Acid!
- Check the product for damage prior to each use. The product must not be used if it exhibits visible damages.
- Do not use the product without the perforated attachment and lint container.
- Never attempt to repair or disassemble the product yourself. In the event of malfunctions or damage, contact the customer service.
- Use only the battery type specified in the “Technical data” chapter.
- When inserting the batteries (battery compartment on the top of the product), always pay attention to the correct polarity.
- Always replace all batteries. Do not use different battery types, brands or batteries with different capacities.

- Remove batteries from the product if they are used up or if the product will not be used for a long period of time. This prevents damage caused by leakage.
- Remove dead batteries from the product immediately and clean the contacts in the product.
- Do not place heavy objects on the product.
- Protect the product from fire and other heat sources, long-term direct sunlight, extreme temperatures, long-term humidity, moisture and impacts.
- Never submerge the motor unit in water or other liquids! Ensure that the motor unit can not fall in water or get wet. Do not use on damp textiles.

ITEMS SUPPLIED

1 x lint shaver

1 x lint container

1 x spacer

2 x AA batteries

1 x cleaning brush

1 x operating instructions

Check the items supplied for transport damage. If you find any damage, contact our customer service department. Remove any films, stickers or transport protection from the product. **Never remove the rating plate and any possible warnings!**

PRODUCT OVERVIEW

- 1 On/Off switch
- 2 Battery compartment cover
- 3 Lint container
- 4 Cleaning brush
- 5 Spacer
- 6 Perforated attachment
- 7 Blade insert



USE

1. Depending on the textile surface, place the spacer on or remove it from the hole attachment.
 - **Coarser** surface: **with** spacer
 - **Finer** surface: **without** spacer
2. Switch on: Slide the On / Off switch to the **on** position.
3. Place the textile which is to be processed on a level, solid surface. Move over the appropriate places on the textile with circular movements.
4. Switch off: Slide the On / Off switch to the **off** position.
5. Clean the product.



If the lint is too tough, the product switches off automatically. In this case, take out the batteries and clean the product.

CLEANING AND STORAGE

- Before cleaning, remove the batteries from the product.
- Do not use harsh or abrasive cleaning agents or cleaning pads to clean. These can damage the surfaces.
- Pull the lint container out of the motor unit and empty it. When it is reinserted, make sure that it engages.
- Remove the spacer if necessary and unscrew the perforated attachment. Clean the blade insert with the cleaning brush supplied.
- Regularly remove lint from the lint brush.
- The lint container, spacer and perforated attachment can be rinsed with clean water, but must be completely dry before re-insertion.
- If necessary, dust off the motor unit with a soft, dry cloth. More intense soiling can be wiped off with a slightly damp cloth.
- Store the product in a dry place that is protected from sunlight and is not accessible to children and animals.

TECHNICAL DATA

Article number:	11096
Model number:	LW-5301
Voltage supply:	3 V \equiv (2 x type AA battery)
ID Operating instructions:	Z 11096 M DS V1.1 0624 as



DISPOSAL



Dispose of the packaging material in an environmentally friendly manner so that it can be recycled.



The adjacent symbol (crossed-out bin underlined) means that used devices should not be disposed of in the domestic waste, but should instead be taken to special collection and return systems.

Owners of used devices must remove from the used device any used batteries or rechargeable batteries which are not encapsulated by the used device and can be removed in a non-destructive way and dispose of them separately (see also the section on battery disposal).

Owners of used devices from private households can take them free of charge to the collection points of the public waste disposal authorities or the disposal points which are set up by manufacturers and distributors under the Electrical Equipment Act so that they can be disposed of in an environmentally friendly way and valuable raw materials can be recovered. If they are not disposed of properly, toxic ingredients may escape into the environment and cause harm to the health of humans, animals and plants. Businesses which market electrical and electronic devices are also obliged to take back used devices.



(Rechargeable) batteries must not be disposed of along with the household waste. Consumers are legally obliged to dispose of (rechargeable) batteries separately.

(Rechargeable) batteries can be handed in free of charge at a collection point of the local authority/district or in retailers so that they can be disposed of in an environmentally friendly way and valuable raw materials can be recovered. If they are not disposed of properly, toxic ingredients may escape into the environment and cause harm to the health of humans, animals and plants.

Only dispose of (rechargeable) batteries when they are discharged. If possible, use rechargeable batteries rather than single-use batteries. In the case of (rechargeable) batteries containing lithium, tape over the poles before you dispose of them to prevent a short circuit. A short circuit may cause a fire or explosion.

Waste prevention makes an even more valuable contribution to protecting the environment. This means if possible, as well as continuing to use or repair, passing it on to another user also represents an ecologically beneficial alternative to disposal.

DS Produkte GmbH

Stormarnring 14, 22145 Stapelfeld, Germany

CUSTOMER SERVICE

Am Heisterbusch 1, 19258 Gallin, Germany

kundenservice@dspro.de

☎ +49 38851 314650*

* Calls to German landlines are subject to your provider's charges.